



# *gMovie™ Player*

user guide

Copyright © 2001 Generic Media, Inc. All rights reserved. The barcode logo, Generic Media and gMovie are trademarks of Generic Media, Inc.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

QuickTime and Apple are registered trademarks of Apple Computer, Inc.

HotSync and Palm OS are registered trademarks, and the HotSync logo and Palm are trademarks of Palm, Inc. or its subsidiaries.

All other trademarks are trademarks of their respective owners.

Before using this software, please read the End User License Agreement that is supplied with this software.

<b>gMovie™ Player</b> .....	<b>4</b>
<b>Quick Start</b> .....	<b>4</b>
<b>Minimum System Requirements</b> .....	<b>4</b>
<b>Installing gMovie™ Player</b> .....	<b>5</b>
WINDOWS .....	5
MACINTOSH .....	5
STARTING gMOVIE™ PLAYER .....	6
PLAYING BACK A MEDIA ITEM .....	7
TO PLAY BACK THE PREVIOUS MEDIA ITEM .....	7
TO PLAY BACK THE NEXT MEDIA ITEM .....	7
TO MUTE THE SOUND .....	7
TO INCREASE/DECREASE THE VOLUME .....	7
TO RETURN TO THE MEDIA LIST .....	7
TO PLAY BACK ALL MEDIA ITEMS CONSECUTIVELY (PLAY SEQUENCE MODE) .....	7
TO DELETE A MEDIA ITEM .....	8
TO VIEW DETAIL INFORMATION ABOUT A MEDIA ITEM .....	8
<b>Menu Commands</b> .....	<b>9</b>
MEDIA .....	9
ABOUT gMOVIE.....	9
DETAILS .....	10
BEAM MEDIA .....	10
DELETE .....	10
PREFERENCES.....	10
LOOP MOVIE PLAYBACK .....	11
LIMIT MAXIMUM VOLUME .....	11
AUDIO CHANNELS.....	11
<b>Uninstalling gMovie™ Player</b> .....	<b>12</b>

## gMovie™ Player

gMovie™ Player is a Palm OS® application which enables the display and playback of multimedia including video, animation and images including sound. gMovie Player supports direct playback from removable storage devices such as the Sony CLIE MemoryStick, MemPlug SmartMedia Adaptor for Handspring Visor and SD/MMC for Palm m500/505.

## Quick Start

- Install the gMovie™ Player application on your Palm OS handheld using the standard Install Tool (Windows) or Install Handheld Files... (Mac) and HotSync.
- HotSync gMovie™ content\* to your handheld device and enjoy!

\* Visit the Generic Media website, [www.genericmedia.com](http://www.genericmedia.com) to find sample gMovie™ content that you can download. You can also learn more about gMovie™ Maker, an easy-to-use tool that allows you to create your own gMovie™ content.

## Minimum System Requirements

The gMovie™ Player application is compatible with Palm OS 3.1 and higher.

## Installing gMovie™ Player

Install the Palm Desktop software to a computer before you follow the instructions below:

### Windows

- Start the Install Tool in the Palm Desktop folder.
- From the list of users, select the appropriate user name.
- Click [Add].
- Navigate to the directory where gMovie™ Player is stored.
- Double-click on the gMovie™ application file. gMovie™ Player is added to the list of files to be transferred to the handheld during the next HotSync operation.
- Click [Done].
- Run the HotSync operation to transfer the file to the handheld device.

The gMovie™ Player icon will appear in the Applications Launcher display.

### Macintosh

- Start the Palm Desktop application.
- From the HotSync menu, choose Install Handheld Files...
- Drag and drop gMovie™ Player onto the Application list or click on Add Item and navigate to the directory where gMovie™ Player is stored.
- Run the HotSync operation to transfer the file to the handheld device.

The gMovie™ Player icon will appear in the Applications Launcher display.



## Basic Operations

### Starting gMovie™ Player

Start gMovie™ Player from the Applications Launcher of the handheld.

The media list appears.



 : displays type of media item

 : displays dimensions of media item in pixels

 : displays duration of media item in seconds

 : displays storage requirements in kilobytes

 : displays details of media item

### Playing back a media item

In the media list, tap the desired media item name.

The media is displayed and automatically played back. The movie will loop by default (see Preferences to change this behavior).



Tap  to stop playback. To restart the media, tap .

Tap  to return to the beginning of the media.

### To play back the previous media item

Tap  at the upper right corner of the display.

### To play back the next media item

Tap  at the upper right corner of the display.

### To mute the sound

Tap the speaker icon, , to toggle sound on/off.

### To increase/decrease the volume

Tap the different volume bars, , to control the volume level of sound.

### To return to the media list

Tap  at the upper right corner of the display.

### To play back all media items consecutively (play sequence mode)

With the stylus, tap and hold  for more than one second. In play sequence mode, the icon will change into . To exit play sequence mode, tap and hold  for more than one second.

### To delete a media item

Display the media item to delete, and then tap the  icon.

Tap Delete...

Tap [OK].

The media item will be deleted, and the display will return to the media list.

### To view detail information about a media item

Not all media items are authored with details. When there are details, the  icon appears to the right of the media item's name in the list view. With the stylus, tap  to display details of the media item:




Details can also be displayed using the Details... menu item while viewing a movie.

## Menu Commands

### Media

This menu is displayed by tapping the  icon when the media list is displayed.




### About gMovie

Select About gMovie from the menu to display version information about gMovie™ Player.



This menu is displayed by tapping the  icon while a media item is playing.



### Details

Detailed information of the active media item is displayed.



### Beam media

You can transmit the currently playing media file to another Palm OS® handheld device via the Infrared port. For details of infrared communications, see your handheld device's manual.

### Delete

To delete a media item, select the item from the file list by tapping on its name. From the menu tap Delete... When the Delete Media dialog is displayed, tap [OK] to perform the deletion, or tap [Cancel].

### Preferences



gMovie Player's preferences panel lets you set default behaviors for the Player.

**Loop movie playback**

Check or uncheck the Loop movie playback to affect what happens when you reach the end of a movie. Checking this box will cause the current movie to loop repeatedly. Unchecking the box will cause the movie to stop playing when it reaches the end of the item. If looping is turned on and the Player is in Play Sequence mode, all movies will play in sequence and the sequence will loop.

**Limit maximum volume**

Check or uncheck Limit maximum volume to control the default audio levels.

**Audio Channels**

For most movies, you'll want to select Both. However, some movies are authored in more than one language, with each language occupying one of the audio channels. If the movie is authored in multiple languages, with Both selected you will hear both audio tracks simultaneously. Use this preference to select one of the channels to listen to one language.

## Uninstalling gMovie™ Player

You can remove the gMovie™ Player application from the handheld by following the procedure below.

Tap the  icon to display the Applications Launcher of the handheld device.

Tap the  icon to display the menu.

Tap App, then Delete...

The Delete dialog will appear.

Tap the gMovie item in the list, then tap Delete...

The Delete Application dialog will appear.

Tap [Yes].

The gMovie™ Player application is deleted from main memory. To cancel deletion, tap [No] instead of [Yes].

Tap [Done].

The display returns to the Applications Launcher.