



Tapwave® Connector for Zodiac™ 1 and 2

Version 1.0

Tapwave Connector for Zodiac 1 and 2

Copyright

© Copyright 2004 Tapwave, Inc. All Rights Reserved. Tapwave is a registered trademark of Tapwave, Inc. The Palm logo, HotSync, Palm OS, Palm, Palm Powered, and the Palm Powered logo are registered trademarks of PalmSource, Inc., and its affiliates. All other brands are trademarks or registered trademarks of their respective owners.

1. Hotsync Connector - Custom 17 Pin Connector

Signal Name	Type	Pin	Description	Notes
Gnd	I	1	Ground	P2A
DC_In	I	2	DC Input. 5.0V±5% @ 1.1A max. Used for charging.	P2A
USB_D+	B	3	USB D+	S1A
USB_D-	B	4	USB D-	S1A
VBUS	I	5	USB VBUS. USB Detect	S1A
HS_Int	I	6	HotSync Interrupt (i.e. HotSync Button)	S1A
RXD	I	7	Receive Data (CMOS level), Serial Line	S1A
Vcc	O	8	Peripheral Supply Voltage Vcc (also used for HS_Int). 3.0-3.3V @ 100mA maximum.	S1A
TXD	O	9	Transmit Data (CMOS level), Serial Line	S1A
ID	I	10	Peripheral ID: A peripheral must tie this to a 1% resistor to ground. A total of 6 peripheral types are supported. Also generates an interrupt when connected. USB Travel Cable: Shorted Keyboard*: 2.00K Mfg. Test Cradle*: 5.0K RxTx Travel Cable: 10.0K USB Peripheral*: 20.0K RxTx Peripheral*: 50.0K Undocked: Open	S1A
DockConnect	I	11	Dock Connect (connects to ground on travel cables)	S1A
RTS	O	12	Request to Send (CMOS level), Serial Line	S1A
CTS	I	13	Clear to Send (CMOS level), Serial Line	S1A
Reserved	B	14	Reserved	S1A
Reserved	B	15	Reserved	S1A
Reserved	B	16	Reserved	S1A
Gnd	I	17	Ground	S1A

* Tentative peripherals (to be determined)

Notes:

1. DC_In – Be sure to observe the proper polarity.
2. P2A – 2A Power Line
3. S1A – 1A Signal Line
4. Serial lines (non USB) will require RS-232 transceiver to communicate with CMOS voltage levels.

2. Peripheral ID Voltage

The Zodiac 1 and 2 can support six different types of attached peripherals not including the unconnected state. The type of peripheral is determined by reading the corresponding voltage across a given peripheral id resistor in the peripheral. Each peripheral type has a unique value resistor.

The attachment of any peripheral (i.e. travel cable, docking the unit in a cradle, or attaching a peripheral) generates an interrupt when the DockConnect line (pin 11) is grounded. Upon receiving the interrupt, the Zodiac will read the peripheral id voltage to determine what corresponding peripheral/device is attached.

The table below shows the peripheral id voltage (range and nominal), corresponding peripheral/device attached and 1% resistor value, and any notes.

Peripheral ID Voltage (1.8V Ref)	Nominal Voltage (1.8V Ref)	Peripheral ID Voltage (1.92V Ref)	Nominal Voltage (1.92V Ref)	Peripheral/Device Attached	Resistor Value 1% Tolerance	Notes
1.925–1.675V	1.800V	2.053-1.787V	1.920V	Undocked	open	
1.625–1.375V	1.500V	1.733-1.467V	1.600V	RxTx Peripheral*	50.0K	
1.325–1.075V	1.200V	1.413-1.146V	1.280V	USB Peripheral*	20.0K	
1.025–0.775V	0.900V	1.093-0.827V	0.960V	RxTx Travel Cable	10.0K	
0.725–0.475V	0.600V	0.773-0.507V	0.640V	Mfg Test Travel Cable*	5.00K	
0.425–0.175V	0.300V	0.453-0.187V	0.320V	Keyboard*	2.00K	No Charging
0.125–0.000V	0.000V	0.133-0.000V	0.000V	USB Travel Cable	0 ohms	

* Tentative peripherals (to be determined)

3. Standard Peripheral Information

Cradle

The cradle is used for charging the Zodiac device, Hotsyncing, and simply holding the Zodiac in a tilted position. The cradle is always used in conjunction with a travel cable (for charging and Hotsyncing) that attaches to the rear of the cradle.

Electrically the cradle is essentially a pass-through device with the addition of a Hotsync button, hence there is no id resistor associated with the cradle -- the travel cable id resistor is used instead. Mechanically the cradle simply holds the device in a tilted position.

Travel Cables

The travel cables can be used stand alone or with the cradle. There are 2 different types of travel cables:

- USB
- Rx/Tx Serial

Each travel cable allows the following:

- Usage with the external AC adapter to charge the Zodiac device.
- Ability to Hotsync the Zodiac device with the user's computer.

The USB travel cable will be shipped with each Zodiac sold. It uses an id resistor of 0 ohms.

The "Rx/Tx Serial" travel cable will be primary used by developers. It uses an id resistor of 10K ohms. In addition this cable also contains electronics (RS-232 transceivers) to convert the TTL/CMOS Rx/Tx signals to the RS-232 levels. Note: The electronics are powered from the Zodiac device (Vcc, pin 8), however the electronics are powered off when the host RS-232 connection is either unplugged or turned off.